

MAD MOUSE™

For 1 – 4 players age 3 years and up. Duration +/- 20 minutes.



Who is this Mad Mouse stealing pieces of cheese from under the cat's nose?

Look out little mouse, the cats are only half-asleep. Whoever steals the cheese will be caught!!

Contents

- 1 electronic mouse
- 4 cat paws
- 9 pieces of cheese
- 1 set of rules

Object of the game

To get the most pieces of cheese by chasing the mouse, and catching it by the tail.

Set Up

- Install 2 x C size Alkaline (LR14-C) batteries (not included)
- Move the switch under the mouse to "ON" position.
- Each child takes a cat's paw
- At the beginning of each round, a piece of cheese is put into the mouse's mouth.
- An adult or the oldest player counts up to three and releases the mouse gently on the ground before the chase begins.

Playing the game

- Everyone plays at the same time. The first player to catch the mouse by its tail using the cat's paw wins the piece of cheese and slips it on its cat's paw. The mouse's tail must be hooked into the hole in the cat's paw in order to retrieve the cheese. If the mouse is caught some other way, start the round over.



- A new piece of cheese is then put in the mouse's mouth and the winner of the previous turn counts to three before releasing the mouse gently on the ground.

End of the game

The game ends when all of the 9 pieces of cheese have been won by the players.

The Winner

The player with the most pieces of cheese is the winner.

CAUTION: Parents, choose a large and safe play area. Before playing, remove any fragile or dangerous items. Beware of furniture edges and carpet corners, as they can slow or stop the mouse from moving. Works best on tile or wood floors and may work on some carpets. The Goliath B.V. and Goliath Games, LLC cannot be held liable for any accidents.

Mad Mouse requires 2 x C size Alkaline (LR14-C) batteries. (not included) - Batteries should always be replaced by an adult. - Use only batteries of the recommended type. - Do not use rechargeable batteries. - Be careful to insert batteries the right way. - Do not mix new and used batteries - Remove used batteries or rechargables from the toy. - Do not short-circuit battery terminals. - Dispose of batteries in a correct way.

Battery installation: Using a screwdriver, loosen the screw until the battery compartment door can be removed. Insert 2 x C size Alkaline (LR14-C) batteries as indicated outside the battery compartment. Replace the battery compartment door and tighten the screw with a screwdriver. Do not over-tighten. ADULT SUPERVISION IS RECOMMENDED WHEN CHANGING BATTERIES.



WARNING:

CHOKING HAZARD — Small parts.
Not for children under 3 yrs.

WARNING! Not suitable for children under 3 years. Risque d'étouffement par ingestion de petits éléments. Ne pas mettre dans la bouche. La présence d'un adulte est recommandée.

Photos non contractuelles : les couleurs, les détails et le contenu peuvent varier de l'illustration.

Distributed by: Goliath B.V. Vijzelpad 80, 8051 KR Hattem – Holland.

© 2010 Goliath Games, LLC Suite 175, 5068 W. Plano Parkway, Plano, TX 75093. Distributed by Goliath B.V. for Longshore, ltd. Made in China. Please keep packaging and instructions for reference. Not suitable for children under 3 years old due to small parts. Mad Mouse is a trademark of Goliath Games, LLC.

www.goliathgames.us



#30549