




Set up:

To install batteries unscrew and lift the battery compartment underneath the base, insert 2AA alkaline batteries using +/- signs inside the battery compartment to align batteries properly.

ADULT SUPERVISION REQUIRED WHEN CHANGING BATTERIES

Place the Dino on the Dino nest by attaching the feet to the base. See illustration below.



Lift up the big leaf and put the eggs in Dino's nest. Turn the switch to "on" at the bottom of the base when you are ready to play. Push the Dino backwards until he locks in position and let the game begin!

Contents:

- 5 Blue eggs
- 5 Red eggs
- 5 Green eggs
- 5 Yellow eggs
- 1 Dino
- 1 Dino nest playing base
- 1 Tweezers (Dino-head shaped)
- 1 Colored Die
- 1 Instruction sheet

The Game:

Dino has stolen the eggs from another dinosaur and he has put them in his nest. The players have to rescue the eggs from Dino and get the eggs back by using the tweezers before Dino attacks.



The youngest player starts by rolling the die. The color shown on the die is the color of the egg that the player has to rescue from Dino's nest.

The player lifts up the leaf as carefully as possible and uses the tweezers to get the egg from the nest.



Note: Younger players can use their fingers instead of the tweezers.

If Dino stays still, the player puts the eggs in front of them and passes the tweezers clockwise to the next player.

When the die shows the side with several colors the player can choose which color egg they take from the nest.

If a player rolls an "X" this means the this player has to skip their turn.

It's exciting to rescue as many eggs as possible... but watch out! If Dino realizes what you're up to....he will attack you... and you are out of the game!

Winner:

The game continues until there is only one player left who didn't get caught by Dino. This player is the winner of the game!



WARNING:

CHOKING HAZARD—Small parts.
Not for children under 3 yrs.

The supply terminals are not to be short-circuited.

Dispose of batteries safely.

Do not dispose of this product in a fire. The batteries inside may explode or leak.

Remove batteries during long periods of non use.

Variation of the game:

You can also play this game over several rounds. After Dino attacks, game play stops and each player counts their rescued eggs and records their score. The eggs are then returned to the nest and a new round begins. The player who rescued the most eggs is the winner of the game.

Battery info:

In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

Non-rechargeable batteries are not to be recharged.

Rechargeable batteries are to be removed from the product before being charged (if designed to be removable).

Rechargeable batteries are only to be charged under adult supervision (if designed to be removable).

Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

Do not mix old and new batteries.

Only batteries of the same or equivalent type as recommended are to be used.

Batteries are to be inserted with the correct polarity.

Exhausted batteries are to be removed from the product.



© 2013 Goliath BV, Vijzelpad 80, NL 8051 KR Hattem.

© 2013 Goliath Games, LLC, 5068 W. Plano Parkway Suite 175, Plano, TX 75093.

Warning: Not suitable for children under three years old due to small parts. Keep this information for future reference. Colors and contents may vary from those illustrated.

Made in China. www.goliathgames.us • www.goliathgames.com



#30565
#3056510-V7-0713