Giggle Wiggle™

## The Twisting Turning Race-to-the-Top Game

Object of the Game:

Be the first player to place all of your colored balls on your section of Giggle Wiggle's hands.

Contents:

- 28 colored balls (7 purple, 7 blue, 7 orange, 7 red)
- 1 Giggle Wiggle Caterpillar
- 1 Giggle Wiggle base
- 1 Sticker Sheet (1 set of eyes, 6 bow ties)

Set Up:

To install batteries, unscrew and open the battery compartment located on the bottom of the game unit (picture 1). Insert 3 AA alkaline batteries, aligning the + and – symbols with the markings on the plastic battery compartment (picture 2). Replace the battery compartment door and tighten the screw. ADULT SUPERVISION IS REQUIRED WHEN INSTALLING BATTERIES.

Picture 1   Picture 2

1.5V   AAx3

Attach the bow tie and eye stickers to Giggle Wiggle, and place the caterpillar into the base. Place the colored balls into the four sections at the base, separated by color.

Playing the Game:

Press the caterpillar button to start Giggle Wiggle moving! (Press again if you want to turn the game off). The race is on! Using your fingers, place your colored balls in the hand above your base section and work your way to the top. You must pick up any of your colored balls that Giggle Wiggle drops before you continue.

Winning the Game:

The first player to successfully place all of their colored balls in their section of Giggle Wiggle's hands wins the game.

Other Ways to Play:

1. Play as normal, but go from the top and work your way down!
2. Play as normal, but place the colored balls in Giggle Wiggle's hands in any order you like!
Remember, you can only place your colored balls into the hands above your own base section.

IMPORTANT! Giggle Wiggle requires 3 AA batteries (not included). Batteries are to be installed in the proper polarity as shown in the instructions. New and old batteries are not to be mixed. Batteries of different types are not to be mixed. Exhausted batteries should be removed. Remove batteries from Giggle Wiggle when it is not expected to be in use for several months. Do not dispose of batteries in fire. Batteries are to be disposed of per your municipality, state or provincial regulations.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or experienced radio/TV technician for help.

30964

CROWN & ANDREWS

Goliath

3096410 - V4 - 0316